

AccuPump Setup and Connections

Pump Groups

The AccuPump modules may be combined so that up to four modules can be operated from the same RS232 logic board. A ribbon cable carries power and logic to each of the modules in the group. Each module has an address jumper whose placement on J4 corresponds to the software's PUMP_NUM. The jumpers may be set in any order for a group of the pumps, however TriContinent's convention for setting the jumpers is shown below.

Note: The firmware residing on the RS232 logic board will service four pumps. If your configuration includes fewer than four pumps, don't send commands to pumps that are not there.

Logic Groups

One logic board is required to provide control to the pump panels and communications to the host computer. If you provide your own cable, be sure the wiring is the same as below.

