

SafetyCaps Thread GL 45

EXTRACTION SYSTEMS



What is included in the scope of delivery?

The shown pictures accord to the scope of delivery.
The air valve with writable change-advice-label and fittings are included.



Easy to install

Thanks to the freely-rotatable cap there are no twistet or tangled capillaries. The PTFE-body stays in position - the change of solvent bottles has never been easier!



Change every 6 months

Since the filter membrane absorbs contaminants from the surrounding air, it is necessary that the valve be replaced every 6 months in order to ensure flawless operation.

GL 45 SafetyCap


D 107 410

 **4x**


Connection of CPC couplings is possible.



E 107 520

 **6x**

Connection of CPC couplings is possible.




Inclined!
SafetyCaps with more than 3 connectors have an inclined body, for barrier-free installation of CPC quick disconnect couplings. (Accessories on page 112.)

F 117 010

 **6 Months**



Up to 150 ml/min.

G 197 010 Stock!

 **6 Months**

10 x



Up to 150 ml/min.



H 160 501

Easily close of unused connectors.



10 x

Blind plug

Fig.	Part No.	Description	 Thread size	 Connector Ø 3.2mm OD
A	107 019	SafetyCap I	GL 45	1x
B	107 909	SafetyCap II	GL 45	2x
C	107 910	SafetyCap III	GL 45	3x
D	107 410	SafetyCap IV	GL 45	4x
E	107 520	SafetyCap VI	GL 45	6x
F	117 010	Air valve for SafetyCaps	UNF 1/4" 28G	-
G	197 010	Air valve for SafetyCaps (10 pc./unit)	UNF 1/4" 28G	-
H	160 501	Blind plug (10 pc./unit)	UNF 1/4" 28G	-